

**MOOG**

# **CUSTOMIZABLE SINGLE-AXIS SERVO DRIVE**

**INSTALLATION & USER'S MANUAL**



*Document No.: CDS36294*

*Revision: C*

*Date: November 2015*

---

**MOOG**

INDUSTRIAL CONTROLS DIVISION

## TABLE OF CONTENTS

<b>CHAPTER 1.0 OVERVIEW .....</b>	<b>1-1</b>
1.1 Introduction .....	1-2
1.2 CSA Models .....	1-3
1.3 Environmental Specifications.....	1-5
1.4 Design Standards .....	1-6
1.5 Power Ratings Specifications.....	1-7
1.6 General functional specifications.....	1-11
<b>CHAPTER 2.0 SAFETY &amp; EMC INSTRUCTIONS .....</b>	<b>2-1</b>
2.1 General .....	2-2
2.2 Safety Regulations.....	2-4
2.3 Electromagnetic Compatibility .....	2-14
2.4 UL Requirements .....	2-25
<b>CHAPTER 3.0 WIRING AND INSTALLATION.....</b>	<b>3-1</b>
3.1 System Components .....	3-3
3.2 Equipment Mounting .....	3-7
3.3 Power Dissipation.....	3-18
3.4 CSA Connector Terminals .....	3-19
3.5 General System Wiring Guidelines .....	3-24
3.6 Sequence of Component Wiring Recommendations.....	3-27
3.7 Three Phase AC Mains Power Source Configuration .....	3-28
3.8 24V Backup Connection.....	3-35
3.9 Internal/External Regeneration (Regen) Resistors – Configurations .....	3-39
3.10 Motors – Installation .....	3-46
3.11 CSA Control Inputs and Outputs.....	3-62
3.12 Communication Interface Wiring and Configuration .....	3-69
3.13 Wiring Summary .....	3-70
<b>CHAPTER 4.0 GETTING STARTED .....</b>	<b>4-1</b>
4.1 Introduction .....	4-1
4.2 Preparation.....	4-1
4.3 Power Supply .....	4-1
4.4 Drive Configuration .....	4-3
4.5 High Power Application.....	4-7
4.6 Autophasing .....	4-8
4.7 Drive Operation Verification.....	4-9
4.8 Drive Tuning .....	4-11
4.9 Power Down Sequence .....	4-16

## TABLE OF CONTENTS

<b>CHAPTER 5.0 FUNCTIONAL OVERVIEW.....</b>	<b>5-1</b>
5.1 Introduction .....	5-2
5.2 CSA Conventions.....	5-2
5.3 Power Interface Section.....	5-3
5.4 Motor Configuration.....	5-9
5.5 Resolver Input .....	5-14
5.6 Encoder Input .....	5-17
5.7 Commutation Module.....	5-22
5.8 Position Feedback.....	5-26
5.9 Velocity Feedback.....	5-27
5.10 Digital Input and Output Functional Description.....	5-28
5.11 Control Loops.....	5-38
5.12 Drive Monitoring & Fault Detection .....	5-56
5.13 Self Protection.....	5-69
5.14 Parameter Storage .....	5-70
<b>APPENDIX A – DATA LOGGER .....</b>	<b>A-1</b>
<b>APPENDIX B – WINDRIVE.....</b>	<b>B-1</b>
B.1 Introduction.....	B-1
B.2 Main Window Features.....	B-6
B.3 Panel Descriptions .....	B-13
<b>APPENDIX C – RESTART INTERLOCK CIRCUITS.....</b>	<b>C-1</b>
C.1 Intended Application .....	C-1
C.2 Restart Interlock Function .....	C-2
C.3 Safety Requirements .....	C-4
C.4 Restart Interlock Circuit .....	C-5
C.5 Restart Interlock Connections.....	C-7
C.6 Safety Relays – Technical Data .....	C-9
C.7 Application Example .....	C-10
C.8 Checking the Restart Interlock.....	C-13
C.9 External Consistency Checks .....	C-14
C.10 Installation and Routine Test.....	C-15
<b>APPENDIX D – MEZZANINE CARD INSTALLATION .....</b>	<b>D-1</b>
D.1 Introduction.....	D-2
D.2 Installation.....	D-2
<b>APPENDIX E – ANALOG I/O MEZZANINE CARD .....</b>	<b>E-1</b>
E.1 Introduction.....	E-2
E.2 Overview .....	E-2
E.3 Configurations .....	E-2
E.4 Analog I/O .....	E-3
E.5 SSI Interface .....	E-5
E.6 Simulated Encoder/Resolver .....	E-6
E.7 PLC Master – DS2110 Slave Arrangement.....	E-9
E.8 Noise Reduction .....	E-9

## TABLE OF CONTENTS

<b>APPENDIX F – DEVICENET™ MEZZANINE CARD.....</b>	<b>F-1</b>
F.1 Introduction .....	F-2
F.2 Connector Pinout.....	F-2
F.3 Network Status .....	F-2
F.4 Available Objects .....	F-3
F.5 MacID and Baud Rate .....	F-3
F.6 Initial Motion Setup.....	F-3
F.7 Fieldbus Scaling Factors.....	F-4
F.8 Units.....	F-4
F.9 PARAM UPDATE in .....	F-5
F.10 Implicit I/O.....	F-5
F.11 Parameter Database Interface.....	F-5
<b>APPENDIX G – ETHERNET MEZZANINE CARD.....</b>	<b>G-1</b>
G.1 Introduction .....	G-2
G.2 Modes of Operation.....	G-2
G.3 Changing IP Address for Ethernet Device .....	G-3
G.4 Changing Commands and Status Registers.....	G-5
G.5 Allen-Bradley RSLogix Configuration with DS2110 .....	G-7
<b>APPENDIX H – ETHERCAT FIELDBUS OPERATION.....</b>	<b>H-1</b>
H.1 Introduction.....	H-2
H.2 Modes of Operation .....	H-3
H.3 EtherCAT LED Indicators.....	H-4
H.4 Communication Services Supported.....	H-5
H.5 Introduction.....	H-6
H.6 FoE File Transfer over EtherCAT .....	H-20
H.7 Default Configuration of PDO Services in ECAT Device.....	H-21
H.8 Example Configuration of PDO Mapping.....	H-22
H.9 DS402 Interface.....	H-25
<b>APPENDIX I – CSA COLDPLATE SERVO DRIVE .....</b>	<b>I-1</b>
I.1 CSA Cold Plate Servo Drive Overview .....	I-1
I.2 CSA Cold Plate Servo Drive Environmental Specifications .....	I-2
I.3 CSA Cold Plate Servo Drive Power Rating Specifications .....	I-2
I.4 Labeling and Certifications .....	I-3
I.5 CSA Cold Plate Servo Drive Dimensions .....	I-5
I.6 General Functional Specifications .....	I-9
I.7 System Wiring Interconnect.....	I-14
I.8 Safety and EMC Instructions.....	I-14
I.9 Installation .....	I-15

**TABLE OF CONTENTS**

<b>APPENDIX J – DUAL CAN/ANALOG MEZZANINE CARD.....</b>	<b>J-1</b>
J.1 Introduction .....	J-2
J.2 Overview .....	J-2
J.3 Configurations.....	J-2
J.4 External P8 Connection .....	J-3
J.5 CAN .....	J-5
J.6 Analog I/O .....	J-9